

Recommended Optical Receptacle Cleaning Procedure

Using "Filtered" or instrument grade
canned air, blow out the terminus
end face.

Inspect receptacle using 10x
magnification minimum, making sure all
loose debris have been removed.

Fiber Optical Receptacle Clean?

Yes.

No further cleaning required.

No.

Using a clean syringe filled with 99% Pure
Isopropyl Alcohol, rinse out the receptacle.

****Note: Pay careful attention not to fully insert
the syringe tip and risk scratching or damaging
the optical Lens.****

Using "Filtered" or instrument grade canned air,
immediately blow out the receptacle.

Inspect receptacle using 10x magnification
minimum making sure all loose debris and
potential alcohol film residue has been removed.

Fiber Optical Receptacle Clean?

Yes.

No further cleaning required.

No.

Repeat.

Recommended Cleaning Products:

- Coventry Swabs: part no. 44070ESD
- Sticklers: Clean Stixx part no. MCC-S12